



- Once system is fully powered up, begin by hitting the  symbol in the bottom right corner. Type 1561 to gain access to programming.
- If possible, you should connect your panel to a local WiFi network. Perform the following steps -

**Network → Wireless → Select correct WiFi name or use WPS**

Tap the back arrow key  3 times.

- Next, check for the latest firmware update.

**Firmware Update → Select newest update → Hit the **

- Next, select installer toolbox.
- Scroll down & agree to **Regulatory Statement**. Follow the next steps -

**Select Advanced Programming → System Configuration →**

**Q101 → 3825 → Hit the **

#### Timers, Delays & Counts Menu

**Q201 → Exit Delay**

**Q202 → Entry Delay**

**Q210 → 30**

#### Reporting Menu

**Q501 → 30**

**Q502 → 7**

**Q517 → Enabled**

- Next, outside of **Advanced Programming** select **Users**
- Update customer's master code.
- Create a duress by selecting the right arrow next to duress user.
- Make Duress user "active"
- Type **2580**, twice.
- Select **Save**.
- Select  button in bottom right corner when finished.

For Wireless or Built In Zone Programming and labels, refer to  
2GIG EDGE installation guide.